

## Panasonic KX-TDA50/50G, KX-TDE100/200 Date Change

### How To Set The Date

1. Press the button directly under PROG in the display
2. Dial \*# Enter 1234 for password
3. System will ask for Sys-Pgm No? System Program number
4. Enter 000
5. Press enter
6. Dial the 2 digit year, Press button under sel+ in the display for the right month, Press the button directly under the arrow facing right to move cursor over to the day, Dial the 1 or 2 digit day
7. Press enter

## Panasonic KX-TDA50/50G, KX-TDE100/200 Time Change

### How To Set The Time:

1. Press the button directly under PROG in the display
2. Dial \*# Enter 1234 for password
3. System will ask for Sys-Pgm No? (System Program number)
4. Enter 000
5. Press enter
6. Press the button directly under next in the display
7. Dial the 2 digit hour, and 2 digit minute. Press sel+ for AM or Pm.
8. Press enter